

Step-by-Step Guide to Using Tamtorque® Sign Fixing Clamps

1. Tamtorque sign fixing clamps are made from Grade 304 stainless steel coil with a deburred, fully-rounded edge and so only minimal hand protection is required.
2. Open the banding coil using a drill with a Tamtorque driver power bit attached. These drill bits, along with the Tamtorque T-bar driver tool, feature a seven-sided socket bit unique to the Tamtorque system. Tamtorque clamps can only be attached and removed using these specially-designed tools, dramatically lowering the risk of tampering, vandalism and theft.
3. Take the object to be secured and carefully thread the clamp through its slots.
4. Position the banding in the correct place around the securing post. There is a range of differently-sized clamps available and each can be exactly adjusted, allowing posts of any shape or size to be accommodated.
5. Use the drill with attached Tamtorque bit to engage the screw housings and tighten the clamp
6. Finish the job by fully tightening the clamp using the T-Bar driver tool.
7. Removing the clamp is just as easy: simply loosen it using the drill with attached Tamtorque drill bit

